



# Tinker Bell Pixie Hollow Laptop

5+

**Oregon**  
S C I E N T I F I C

Dear Parent/Guardian,

Thank you for choosing **Tinker Bell Pixie Hollow Laptop**.

Designed with fun in mind,

**Tinker Bell Pixie Hollow Laptop** is packed with stimulating games and activities that will make an invaluable contribution to your child's development.

The activities to help improve your child's skills include: language, mathematics, logic, memory, music and hand-eye coordination.

**Tinker Bell Pixie Hollow Laptop** provides a dependable and realistic introduction to computers and encourages creativity and independent learning.

Learning has never been so much fun!

Tinker Bell and associated trademarks and trade dress are owned by, and used under license from, Disney, Inc. © 2010 Disney, Inc. All Rights Reserved. www.disneyfairies.com

## Table of Contents

|  |                               |
|--|-------------------------------|
| <b>Chapter 1</b>                                     | <b>Chapter 5</b>              |
| About <b>Tinker Bell Pixie Hollow Laptop</b> ..... 1 | <b>Activities</b>             |
|  | Vocabulary .....11            |
| <b>Chapter 2</b>                                     | Spelling .....12              |
| Getting Started ..... 3                              | Keyboard .....13              |
|  | Mathematics .....13           |
| <b>Chapter 3</b>                                     | Logic .....14                 |
| Game Rules and Selection ..... 6                     | Memory .....15                |
|  | Music .....16                 |
| <b>Chapter 4</b>                                     | Hand-Eye Coordination .....16 |
| Useful Features and Controls.....8                   | 2-Players.....17              |
|  | <b>Chapter 6</b>              |
|  | Troubleshooting .....18       |

## Chapter 1

### About Tinker Bell Pixie Hollow Laptop

#### Features

- 30 Activities
- Vocabulary
- Spelling
- Keyboard
- Mathematics
- Logic
- Memory
- Music
- Hand-Eye Coordination
- 2-Player mode

#### Multimedia

- Digital Sound/Animation

#### Display

- LCD screen (85mm x 40mm)

#### Audio

- The voice of Tinker Bell


#### Energy Saving Features

- Automatic shut-down

**Tinker Bell Pixie Hollow Laptop** is supplied with the following parts: (Please contact your retailer if any parts are missing.)

#### 1 - Unit

#### 2 - Instruction Manual



### Storage & Care

To ensure that the product enjoys a long life, please follow these simple rules:

- Regularly examine the unit for damage to the cord, plug, enclosure and other parts. In the event of such damage, the unit must not be used with the adaptor until the damage has been repaired.
- Always disconnect the power supply before cleaning.
- Keep the unit clean by wiping the exterior of the unit with a dry cloth.
- Avoid getting the unit wet.
- The unit should not be dismantled.
- Always store the unit away from direct sunlight and high temperatures.
- Avoid leaving the unit in a car where it is exposed to direct sunlight.
- The unit should not be subjected to extreme force or shock.
- Please keep this manual for future reference.

### Starting Tinker Bell Pixie Hollow Laptop

Open the unit by pushing in the lock at the front of the laptop and lifting up the laptop cover. Turn on **Tinker Bell Pixie Hollow Laptop** by pressing the button located at the top right corner of the keyboard. At the end of a session, remember to turn off the power by pressing the same button.

### Auto-off

If there is no input on the unit for a couple of minutes, the unit will automatically turn itself off to conserve power. To start playing again, press the button to turn the unit back on.

### Volume and Contrast Keys

Press to adjust the volume and contrast, they are located at the top left of the keyboard. The choices are high, medium and low.

### Tinker Bell Secret Code

Once the player has fully completed an activity, a secret code will be unlocked at the end of the game (except in Tink Words, Symphony, Flap Your Wings and 2-Players' games). There are 8 secret codes to be uncovered. The player can press "Tinker Bell Secret Code" to review the codes they have gathered and press to exit and choose another activity at anytime. The secret codes will act as keys to unlock an engaging website at www.pixiehollow.com. Once the secret codes has been entered on the website, the player can continue to interact and have fun with Tinker Bell.

### Player 1/2

Press the player keys to answer during 2-Players mode.


### Backlight On/ Off

Press to turn the product's backlight on and off.

### Music On/ Off

Press to turn the background music on and off during the game category, game selection and game play (except during music games).

### Exterior Features



## Chapter 2

### Getting Started


**Tinker Bell Pixie Hollow Laptop** operates on 3 AA-size batteries or a 6V AC/DC adaptor (not included).

### Battery Installation

1. Make sure the unit is turned off.
2. Open the battery cover at the back of the unit using a coin or a straight blade screwdriver.
3. Insert 3 AA-size batteries (note the correct polarity: +, - ).
4. Replace the cover.


### Caution

- Do not mix different types of batteries or old and new batteries together.
- Only use batteries of the same or equivalent type as recommended.
- Remove all batteries when replacing.
- Remove batteries if the unit is not going to be used for long periods of time.
- Do not dispose of batteries in fire.
- Do not recharge non-rechargeable batteries.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Remove exhausted batteries from the toy.
- Do not short-circuit the supply terminals.



### AC/DC Adaptor Connection

Please turn off the unit before plugging in the AC/DC adaptor to prevent damage to the unit. Plug the adaptor into the adaptor socket located on the left hand side of the unit. Plug the adaptor into a wall outlet.



### Caution

- The unit must not be connected to a power supply greater than 6V.
- Only use the recommended adaptor.
- The adaptor is not a toy.
- Do not short-circuit the supply terminals.
- Toys should be disconnected from the power source before cleaning.
- Due to AC/ DC adaptor connection, this product is not suitable for children under 36 months to use without adult supervision.
- In an environment prone to static discharge, the unit may malfunction.
- To reset, press the reset button at the back of the laptop, remove the batteries or disconnect the adaptor for at least 10 seconds before connecting the power supply again.

## Chapter 4

### Useful Features and Controls

#### Keyboard

**Tinker Bell Pixie Hollow Laptop** features a fully functional computer keyboard.

#### Game Menu

Press the button to go to the main category selection menu.

#### Instant Access Buttons


Pressing an instant access button will bring the player to a list of activities in the specified category.

#### Arrow Keys and Touch Pad

Use the touch pad and the arrow keys to view a selection or navigate inside the games where available.

#### Confirm buttons

Press to confirm a selection. They share the same function as the enter key.



## Chapter 3


### Game Rules and Selection

There are 9 categories in **Tinker Bell Pixie Hollow Laptop**: Vocabulary, Spelling, Keyboard, Mathematics, Logic, Memory, Music, Hand-Eye Coordination and 2-Players.

The category selection menu will scroll to the next category every 5 seconds.

The player can also use the , arrow keys or the touch pad and press to select a category. All the games under a category are listed in the game selection menu. The player can use the , arrow keys or the touch pad to scroll through the activity names and press to play.

At anytime, press the instant access buttons to go straight to a particular game category or press the menu key to go to the start of the category selection list.



### Attempts

In most activities the player will have three attempts per question. Tinker Bell will reveal the correct answer after three incorrect attempts. If there is no input after 15 seconds, Tinker Bell will repeat the instruction prompt.

### Scoring

At the end of each game round (generally consisting of ten questions), after the successful completion of all the levels in an activity or if time has run out, a summary score screen will appear so the player can see how well they have done. After the successful completion of all the levels in an activity, a secret code will be unlocked, followed by a 'Play Again?' screen, allowing player to choose whether they want to play again or exit and choose another activity.

### Time Limit

For most games, the player has a time limit to select an answer, with the length depending upon the type of question and game.



## Chapter 5

### Spelling

#### Tidy Garden


Delete the extra letter to spell a word.

#### Fairy Spell

Guess a word with the given hints. Two hints will be shown per question, one at a time. Letter choices are available for selection at the early stages, at higher levels the letter must be typed in.

#### Ladybird Order

Spell out the animated vocabulary word which is shown on the screen.



### Keyboard

#### Letter Fireflies

Type out the word before the firefly scrolls off the screen.

#### Sprinkle The Words

Type as fast as possible to stop the words from reaching Tinker Bell.


#### Stop The Sproutlings

Use the arrow keys and type the letters shown on the screen before they reach the bottom.

### Mathematics

#### Let's Add

Solve the addition equation (vertical sums).



### Repeat

Press **Repeat** to repeat a sentence or an instruction.

### Help

Press **Help** to receive hints to a question. Using this function will reduce the total score for the current question. Note: Not all games have this function.

### Answer

Press **Answer** to reveal the correct answer to a question. The player needs to think carefully before pressing this button as no points will be awarded for that question.

### Delete

Press **Delete** to remove the previously entered letter or number.

### Enter

Press **Enter** to confirm a selection.

### Demo

Press **Demo** to see a demonstration of some of the exciting features and activities in **Tinker Bell**

### Pixie Hollow Laptop.

### ESC

Press **Esc** to return to the previous screen or to exit a game.

### Activities

#### Vocabulary

##### Tink Words


Select a topic and learn a word.

##### Pair Up

Find the words that best match one another - The 2 categories of game play are "Parent-Child Match Up" and "Same-Thing Match Up".

##### Go Plural

Type the correct plural form of the noun. There are 3 levels with the following types of nouns:  
1) add 's'  
2) nouns that end in 'ch', 'sh', 's' or 'x' add 'es'  
3) 'y' becomes 'ies'  
4) special cases



10

11

#### Tink's Take Away

Solve the subtraction equation.

#### Plus Or Minus

Select the correct operation sign (+ or -) for the equation.

#### Right Time

Select the correct time shown on the clock.

#### Sproutlings Lineup

Select the numbers in the correct order, as instructed.


### Logic

#### Mouse Race

Use the arrow keys to guide the mouse through the checkpoints without repeating any steps or crashing into the sproutlings.

#### Complete The Pattern

Type in the answer and press enter, to complete the sequence.



14

15

#### Which Is Different

Find the item or character that looks different from the rest.

### Memory

#### Fairy Numbers

Remember and enter the number sequence shown as Tinker Bell flies past.

#### Match It


Remember what is shown and identify it from a selection of three similar objects or characters.

#### Number Songs

Remember the sequence of the tones played and repeat it.

#### Seed Shuffle

Watch carefully and remember which fairy has the seed.



Conforms to safety requirements of ASTM F963, EN71 Parts 1, 2 and 3 and EN62115.

In an effort to continually improve our products, the actual screen display on the product may differ slightly from the diagrams shown. Please retain this manual for future reference.

### Oregon Scientific Australia Pty Limited

G01, 4 Talavera Road,  
North Ryde, NSW 2113, Australia  
Tel: 61 1300 300 155  
Email: info@oregonscientific.com.au

## Chapter 6

### Troubleshooting

Developing learning products is a responsibility that we at Oregon Scientific take very seriously. We make every effort to ensure the accuracy and appropriateness of the information which forms the value of our products. However, errors can sometimes occur. It is important for you to know that we stand behind our products and we encourage you to call our Technical Support Team with any problems and/or suggestions that you might have. Our Technical Support Team will be happy to help you.

Before contacting us on 61 1300 300 155, please carry out the following simple checks - it may save you the time of an unnecessary service call:

#### No display

Are the batteries installed properly?  
Do the batteries need replacing?

#### Black-out screen or abnormal display

Disconnect the power supply by removing batteries for at least 10 seconds before connecting the power supply again.

#### In an environment prone to static discharge, the unit may malfunction.

To reset, remove the batteries for at least 10 seconds before connecting the power supply again.

18

### Warning:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
• There may be small parts that can cause abuse and/or damage to the unit.  
• Warning! Not suitable for children under 36 months. Choking hazard.



#### DISPOSAL

Do not dispose of this product as unsorted municipal waste. Collection of such waste separately for special treatment is necessary.

300102634-00001-10 AU

16

17

19

20